

# ednet Máquina de plastificar, A4

91610  
EAN 4054007916105



## Laminator, A4, 80-125 Mic Heating: Mica Plate, white

Proteja ou melhore as suas fotografias, documentos, cartões de visita, documentos de identidade e muito mais com uma dimensão até DIN A4 com a máquina de plastificar A4 ednet. Graças ao breve tempo de aquecimento de 3 minutos, a máquina de plastificar está rapidamente pronta a funcionar. Os LED de estado informam-no sobre o estado. Graças à tecla ABS (sistema anti-bloqueio), é possível evitar ou remover rapidamente uma acumulação de películas. Esta função recolhe o documento para o ponto de alimentação. Podem ser utilizadas películas com uma espessura de 80 a 125 micrones com uma largura até 230 mm. A velocidade de plastificação é de 400 mm/min.

### Proteja ou melhore as suas fotografias, documentos, cartões de visita, documentos de identidade e muito mais com uma dimensão até DIN A4

- Proteja ou melhore as suas fotografias, documentos, cartões de visita, documentos de identidade e muito mais com uma dimensão até DIN A4

- Adequado para dimensões de plastificação: DIN A4, DIN A5, DIN A6, cartões de visita
- Espessura da folha: 80 a 125 micrones
- Largura de plastificação: até 230 mm
- Tempo de aquecimento: 3 min.
- Velocidade de plastificação: 400 mm/min.
- ABS (sistema anti-bloqueio)/tecla de desbloqueio de acumulação
- Design compacto e moderno
- Indicação de estado LED
- Elemento de aquecimento: Placa de mica (placa de mica cerâmica)
- Potência absorvida: 260W
- Tensão de entrada: 220-240, 50 Hz
- Dimensões: C 35,5 x L 13,5 x A 5,8 cm
- Peso 0,7kg
- Cor: Branco
- Certificação GS

### Package contents

- Máquina de plastificar, A4
- Manual de instruções

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm <sup>3</sup>
Packaging Unit Carton	6	5.10	38.00	31.50	20.70	24,777.90
Packaging Unit Inside	1	0.85	36.50	15.00	6.40	3,504.00
Packaging Unit Single	1	0.85	36.50	15.00	6.40	3,504.00
Net single without Packaging	1	0.70	35.50	14.60	5.80	0.00

**More images:**



**Safety notes**

- Read the operating instructions carefully and completely before using the appliance for the first time.
- Always place the appliance on a level and dry surface. It must be freely accessible from all sides. It is not advisable to use an extension cable!
- Do not open the laminator or repair it yourself. Take it to your specialist dealer if it has been damaged or contact our service hotline.
- Only use film pockets of the correct size (max. up to A4) and thickness (80 to 100 micrometers). Foil pockets that are too thin can lead to a blockage inside the device.
- Do not touch any hot surfaces of the appliance after it has been put into operation.
- For safety reasons, the laminator must not be used by children unless they are supervised by an adult.
- Do not operate the appliance outdoors or near water.
- Do not use the device to hot laminate materials that are sensitive to heat, such as thermal fax paper. These materials are only suitable for cold lamination.
- Do not spill or pour any liquid on the appliance and do not allow it to enter the appliance.
- Do not insert any metal objects into the appliance. Do not reach into the appliance with your fingers.
- The laminator is not suitable for continuous commercial use. It is advisable to set the appliance switch to the "O" position for 30 minutes after it has been in operation for approx. 30 minutes.
- The socket outlet must be located near the appliance and must always be easily accessible.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH  
Auf dem Schüffel 3  
Lüdenscheid, Germany  
<https://www.assmann.com>  
[info@assmann.com](mailto:info@assmann.com)