

DIGITUS Адаптер USB для параллельного подключения принтера

DC USB-PM1
EAN 4016032166306



USB to Centronics Printer Cable USB to IEEE 1284, CENT36 M, Length 1,8 M

Этот кабель предназначен для подсоединения принтера с интерфейсом Centronics к порту USB персонального компьютера или ноутбука. Параллельный порт можно использовать для подключения второго принтера, сканера или цифровой камеры. Кабель имеет разъем USB и штекер Centronics с 36 контактами и скоростью передачи данных 1,2 Мбит/с. Кабель получает питание по шине.

Устанавливается в считанные секунды - идеально подходит для использования с современными ноутбуками имеющими лишь порты USB и настольными компьютерами

- Соответствует спецификации USB версии 1.1.
- USB вилка и 36-контактный разъем Centronix
- Поддержка EPP / ECP и двунаправленной передачи данных
- Скорость передачи данных до 1.216 Мбит / с (ECP режим)
- Поддерживает Windows 10, 8.1, 8, 7, Vista, XP, Mac OS X и Linux
- Длина кабеля: 1.8 м

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	30	7.40	50.50	32.30	47.60	77,642.70
Packaging Unit Inside	1	0.25	23.50	15.00	6.00	2,115.00
Packaging Unit Single	1	0.25	23.50	15.00	6.00	2,115.00
Net single without Packaging	1	0.11	8.00	8.00	2.20	63.00

More images:



Safety notes

- Overloading can lead to overheating and damage to the appliance or the connected peripherals.
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external

power supply. Otherwise, the device could be overloaded or functional problems could occur.

- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.

EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
<https://www.assmann.com>
info@assmann.com