# DIGITUS® □□□□□□□□□ □□□□□□□ □ TFT-□□□□□□□□ 19" (43,2 □

**DS-72211-4UK**

**EAN 4016032450108**




**Modularized 48,3cm (19") TFT console with 8 port CAT 5 KVM, UK keyboard, RAL 9005 black**

□□□□□□□□□□ □□□□□□□□□□ □□□□□□□□□□□□ KVM-□□□□□□□□ DIGITUS® 19" (TFT) □□□□□□□□□□ □□□□□□□□□□ □□□□□□□□□□ □□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□ □□□□ □□

□□□□□□□□□□□□□□ □□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□ □□□□□□□ □□□□□□□□□

- TFT-□□□□□□□□ 48.3 □□ (19"), □ □□□□□□□□□□□□□□□ □□□□□□□□□□□□ □□□□□□□□□ □□□□□□□□
- □□□□□□□□□□□□: 1366x768 □□□□ 60 □□
- □□□□□□□□ □□□□□□□□□ □□ 85 % □□□□□□□ □□□□□□
- Ko□□□□□□□□□□□□□□: 1000:1
- □□□□□□□□□□□□□□□: 16,7 □□□□ □□□□□□□
- □ □□□□□□□□□□ □□□□□□□ 8-□□□□□□□□□□ KVM-□□□□□□□□□□□□□□□□ Cat.5
- □ □□□□□□□□□□ □□□□□□□ □□□□□□□□□□□□□ □□□□□□□□□□□□□ (□□□□□□□□□□□□□□□□□□□)
- □□□□□□□□□□□ □□□□□□□ □□□□ □□□□□ □ □□□□□□ □□□□□□□□□□□□□□□□□□□ □□□□□□□□□□
- □□□□□□□□ □□□□□□□□□□ □□□□□□□□□□□□□ □□ □□□□□□□□□□□□□ □□□□□□, □□□□□□□□□ TFT □□□□□□□□□□□□□□ □□ 120 □□□□□□□□□□.
- □□□□ □□□□□□□: 19,15 □□
- □□□□□□□□□□ □□□□□□□□□□□□ □□□□□□□□ □□□□□□□□□□ □□□□□□□□□□ □□□□□□□□□□□□□□□
- □□□□□□□□□□□□□□□□□ □□□□□□□ □□ □□□□□□□□□□ □□□□□□ (1U), □□□□□□□ (RAL 9005)

- 8 □□□□□□□ □□□□□□□ □□□□□□□□□□ 5

**Attributes**

- Cascading possible: yes
- Interface: CAT 5
- Keyboard Layout: UK
- Number of ports: 8
- Screen size: 19 inch

**Package contents**

- □□□□□□□□□□ □□□□□□□□ 19"
- 8-□□□□□□□□□□ KVM-□□□□□□□□□□□□□□□□ □□□□□□□□□□ 5
- □□□□□□□□□□□□
- □□□□□□□□ □□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□
- □□□□□ □□□□□□□□□
- □□□□□□□□□□ □□□□□□□□□□
- 8 □□□□□□□ □□□□□□□ □□□□□□□□□□ 5

**Logistics**


| | Number (pcs) | Weight (kg) | Depth (cm) | Width (cm) | Height (cm) | cm³ |
|---|---|---|---|---|---|---|
| **Packaging Unit Carton** | 1 | 23.36 | 81.00 | 70.50 | 19.50 | 111,355.00 |
| **Packaging Unit Inside** | 1 | 23.36 | 81.00 | 70.50 | 19.50 | 111,355.00 |
| **Packaging Unit Single** | 1 | 23.36 | 81.00 | 70.50 | 19.50 | 111,355.00 |
| **Net single without Packaging** | 1 | 12.54 | 69.50 | 48.00 | 4.50 | 0.00 |

**More images:**







**Safety notes**

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable or plug is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
https://www.assmann.com
info@assmann.com