

# DIGITUS® Consola KVM modular HD LCD com TFT de 17", ligação KVM HDMI de 16 portas, touchpad, layout de teclado suíço

DS-72220-7CH

EAN 4016032491910



## Consola TFT HD modular de 43,2 cm (17") com 16 portas HDMI, RAL 9005 preto, teclado CH

Grças à sua conceção modular, a consola DIGITUS® 17" HD TFT oferece uma vasta gama de opções de configuração individuais, de modo a que a consola possa ser personalizada de acordo com a área de aplicação. Isto torna a consola económica e pode ser actualizada ou convertida com módulos adicionais em qualquer altura. A configuração flexível garante que a consola é altamente preparada para o futuro. A consola modular é composta por um monitor de 17", um comutador KVM HDMI de 16 portas e o touchpad.

### Máxima flexibilidade na gestão do parque de servidores

- Resolução: 1920x1080 a 60 Hz
- A consola cria até 85 % mais espaço
- Relação de contraste: 1000:1
- Suporta: 16,7 M de cores
- Comutador KVM HDMI de 16 portas incluído
- Rato tátil com dois botões de função
- A consola pode ser completamente retirada do armário do servidor e o ecrã TFT pode ser inclinado 120 graus

- Bloqueio de segurança da consola para evitar danos
- Interface: HDMI
- Número de portas: 16
- Tamanho do ecrã: 17 polegadas

### Attributes

- Cascading possible: yes
- Interface: HDMI
- Keyboard Layout: CH
- Number of ports: 16
- Screen size: 17 inch

### Package contents

- Consola modular de 17"
- Comutador KVM HDMI de 16 portas
- Disposição do teclado: CH
- Manual do utilizador
- Unidade de alimentação eléctrica
- Material de montagem
- 16 Cabo de ligação HDMI + USB

## Logistics

	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	1	16.60	75.50	63.00	20.50	97,508.20
Packaging Unit Inside	1	16.60	0.00	0.00	0.00	0.00
Packaging Unit Single	1	16.60	71.00	59.00	15.00	62,835.00
Net single without Packaging	1	13.93	65.00	48.00	4.50	0.00

**More images:**



**Safety notes**

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
  - The mains cable or plug is damaged or worn;
  - Liquid has penetrated the appliance;
  - The device has been exposed to rain or water;
  - The device has been dropped or the housing has been damaged;
  - The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH  
 Auf dem Schüffel 3  
 Lüdenscheid, Germany  
<https://www.assmann.com>  
[info@assmann.com](mailto:info@assmann.com)