1

# DIGITUS USB Type-C<sup>™</sup> OTG 3-Port HUB + Card Reader

DA-70243 EAN 4016032425830





### DA-70243 USB 2.0 Type-C HUB with Cardreader, 3x 3x USB 2.0. 1x SD, 1x MicroSD Port, Aluminium

Expand your computer featuring a USB Type-C<sup>™</sup> port or Android Mobile phone with three additional USB 2.0 ports as well as a SD or Micro SD card slot. Thanks to the easy plug-and-play configuration you don't have to install drivers or change system settings.

## Expand your USB-C<sup>™</sup> notebook or Android smartphone, tablet with three additional USB 2.0 ports as well as a SD or Micro SD card slot.

- USB 2.0 / 480Mbps Highspeed
- Compatible with Mac OS, Windows 10, and Google Chrome OS
- Cable length: 15 cm •

- Size: 81x23x16mm
- Weight: 30g •

## Attributes

- Broj priključaka: 3 •
- USB-A (2.0) konektori: 3
- USB-A (3.0) konektori: 0
- . USB-C konektori: 0 •
- USB-norma: USB 2,0 •
- USB-C proizvodi: Da

## Package contents

- OTG USB 2.0 Hub & Card Reader
- Instruction manual •

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	100	7.25	46.00	35.00	35.00	56.35
Packaging Unit Inside	1	0.07	14.00	8.50	4.50	535.50
Packaging Unit Single	1	0.07	14.00	8.50	4.50	535.50
Net single without Packaging	0	18.00	8.10	2.33	1.63	30.76

### More images:









## Safety notes

- Overloading can lead to overheating and damage to the appliance or the connected peripherals.
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external power supply. Otherwise, the device could be overloaded or functional problems could occur.
- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.

## EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany https://www.assmann.com info@assmann.com