

# DIGITUS® Modular HD LCD KVM console with 17" TFT, 16-port HDMI KVM connection, touchpad, German keyboard layout

DS-72220-7GE

EAN 4016032491941



## Modularized 43,2cm (17") HD TFT console with 16-port HDMI, RAL 9005 black, GE keyboard

Thanks to its modular design, the DIGITUS® 17" HD TFT console offers a wide range of individual configuration options so that it can be adapted to the area of application of the console. This makes the console cost-saving and it can be upgraded or retrofitted with additional modules at any time. The flexible configuration guarantees that the console is highly future-proof. The modular console consists of a 17" monitor, a 16-port HDMI KVM switch and the touchpad.

### Maximum flexibility in managing the server farm

- Resolution: 1920x1080 at 60Hz
- Console creates up to 85 % more space
- Contrast ratio: 1000:1
- Supports: 16.7 M colors
- 16-port HDMI KVM switch included
- Mouse touch board with two function buttons
- The console can be completely pulled out of the server cabinet and the TFT screen can be tilted by 120 degrees
- Console safety lock to prevent damage
- Interface: HDMI
- Number of ports: 16

- Screen size: 17 inch
- Power consumption specification: Input: 100 – 240V AC, Output: DC 12V / 4A
- Device Power consumption (max.): 30W
- DC plug size: 5.5 x 2.1 mm
- DC plug electrode: Inside ( + ), Outside ( - )
- Cable length: 1.8 m

### Attributes

- Broj priključaka: 16
- Cascading possible: Da
- Raspored tipkovnice: DE
- Sučelje: HDMI
- Veličina ekrana: 17 inča

### Package contents

- Modular 17" console
- 16-port HDMI KVM switch
- Keyboard with German keyboard layout
- User manual
- Power supply unit
- Mounting material
- 16 HDMI + USB connection cable

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm <sup>3</sup>
Packaging Unit Carton	1	3.20	62.50	75.50	18.60	87,768.80
Packaging Unit Inside	1	3.20	0.00	0.00	0.00	0.00
Packaging Unit Single	1	3.20	62.50	75.50	18.60	87,768.80
Net single without Packaging	0	13.91	44.50	50.85	4.50	10,182.70

**More images:**



**Safety notes**

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
  - The mains cable or plug is damaged or worn;
  - Liquid has penetrated the appliance;
  - The device has been exposed to rain or water;
  - The device has been dropped or the housing has been damaged;
  - The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH  
Auf dem Schüffel 3  
Lüdenscheid, Germany  
<https://www.assmann.com>  
[info@assmann.com](mailto:info@assmann.com)