

# DIGITUS Modular console with 19" TFT (48.3cm) & touchpad

DS-72211 EAN 4016032447580





# Modularized 48,3cm (19") TFT console without keyboard, without KVM module, RAL 9005 bk

Due to its modular design, the DIGITUS® 19" TFT console offers a multitude of individual configuration possibilities, so that it can be adjusted to the area in which the console is being used. As a result, the console is economical and can be upgraded and/or converted at any time with further modules. Due to the flexible configuration, a high level of future security of the console is thus guaranteed. The modular console consists of a 19" monitor and the touchpad. A keyboard, KVM module and the appropriate set of cables are required to operate the console. The accessories are offered in the most diverse versions.

# Highest degree of flexibility during the administration of the server farm

- Non-reflective and break-proof TFT monitor 48.3 cm (19")
- Resolution: 1366x768 at 60 Hz
- Console could save almost 85 % space

- Contrast rate: 1000:1
- Supports: 16.7 M colors
- Mouse touch board with two function button
- The console can be totally pulled out from the cabinet and the TFT screen can be tilted by 120 degrees
- Gross weight: 19,15 kg
- · Front panel with lock to prevent damage by accident
- Space-saving steel sheet housing (1U height), black (RAL 9005)

### Attributes

Cascading possible: noScreen size: 19 inch

## Package contents

- Modular 19" console
- · Quick installation guide
- Power Supply
- Mounting material

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Inside	1	23.36	81.00	70.50	19.50	111,355.00
Packaging Unit Single	1	23.36	81.00	70.50	19.50	111,355.00
Net single without Packaging	1	19.56	81.00	70.50	19.50	111,355.00



#### More images:







### Safety notes

- · This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- · Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- · If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings
  must not be blocked or covered.
- · Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- · If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- · If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
- The mains cable or plug is damaged or worn;
- Liquid has penetrated the appliance;
- The device has been exposed to rain or water;
- · The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

## EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany https://www.assmann.com info@assmann.com