# DIGITUS® □□□□□□□□□□□ □□□□□□□ USB Bluetooth® 4.0

**DN-30210-1**

**EAN 4016032325062**



**Bluetooth V4.0 + EDR Tiny USB Adapter, Class 2 CSR chipset**

Bluetooth V4.0 + EDR Tiny USB Adapter, Class 2,CSR chipset

- □□□□□□□□□□ □□□□□ □□□□□□□□: Bluetooth® 4.0 □ Bluetooth® 3.0
- □□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□
- □□□□□□□ CSR Bluetooth®
- □□□□□□□□□□ □□□□□□□□□□ □□ 10 □
- □□□□□□□□□□□□□□□□□ □□□□□□□□□: A2DP, AVRCP, □□□□□□□□□□□□□□□□□□□□□ □□□□□, □□□□□□ □□□□□□□□□□□□□□□□□□□□

**More images:**









**Safety notes**

- Overloading can lead to overheating and damage to the appliance or the connected peripherals.
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external power supply. Otherwise, the device could be overloaded or functional problems could occur.
- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.

**EU responsible person**

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
https://www.assmann.com
info@assmann.com