DIGITUS 8 Port Gigabit Switch, Unmanaged

DN-80064-1 EAN 4016032486428



Gigabit Ethernet Switch 8-port, unmanaged, Desktop

With this Gigabit Ethernet Switch you can easily expand your Network with eight additional RJ45 Network ports. Thanks to the Auto-MDI/MDI-X cable detection every port can be used as uplink. Automatic detection of network speeds 10/100/1000Mbps. No driver of software installation necessary.

Best for quick and easy network expansion!

- 8-port 10/100/1000Mbps Gigabit Ethernet Desktop Switch
- Compliant to the network standards IEEE 802.3, IEEE 802.3u and IEEE 802.3ab
- Auto-negotiation for 10/100/1000 Mbps
- Auto-MDI/MDI-X detection for each RJ-45 port
- Noiseless design without fan
- External power supply
- Operating system independent, supports e.g. Windows, Mac OS, Linux and Sun

DIGITUS

Package contents

- Switch
- Power Supply
- Quick Installation Guide

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	50	3.98	0.00	0.00	0.00	0.00
Packaging Unit Inside	1	0.08	0.00	0.00	0.00	0.00
Packaging Unit Single	1	0.08	0.00	0.00	0.00	0.00
Net single without Packaging	0	0.00	0.00	0.00	0.00	295.36

More images:







1











Safety notes

- This product is intended for indoor use only.
- · Read all instructions and follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings
 must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- · Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- · If any of the following conditions occur, unplug the appliance and return it to an authorized service centre for repair
- The mains cable, power supply unit or plug for the power supply is damaged or worn;
- Liquid has penetrated the appliance;
- · The device has been exposed to rain or water;
- The device has been dropped or the housing has been damaged;
- The function of the device has obviously changed;
- The appliance cannot be operated as described in the operating instructions.

EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH Auf dem Schüffel 3 Lüdenscheid, Germany https://www.assmann.com info@assmann.com