## **USB to Parallel Printer Cable**

### DC USB-PM1 EAN 4016032166306





# USB to Centronics Printer Cable USB to IEEE 1284, CENT36 M, Length 1,8 M

This cable is for connecting a printer with Centronics interface to the USB port of the PC or notebook. You can keep your parallel port free for a second printer, scanner or digital camera. The cable has a type A USB connector and a 36 pin Centronics plug with a transfer rate of 1,2 MB/s. The cable is bus powered.

# Installation within seconds - perfect to be used with notebooks and desktops without a parallel interface

- Compatible with USB specification revision 1.1
- USB A male to CENT 36-pin male connector
- Supports EPP / ECP and bidirectional printing
- Data transfer rate up to 1,216 Mbps (ECP mode)
- Supports Windows 10, 8.1, 8, 7, Vista, XP, Mac OS X and Linux
- Cable length: 1.8 m

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	30	7.40	50.50	32.30	47.60	0.00
Packaging Unit Inside	1	0.25	23.50	15.00	6.00	2,115.00
Packaging Unit Single	1	0.25	23.50	15.00	6.00	2,115.00
Net single without Packaging	0	0.11	8.00	8.00	2.20	140.80

### More images:





### **Safety notes**

- $\bullet \quad \hbox{Overloading can lead to overheating and damage to the appliance or the connected peripherals.}\\$
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external power supply. Otherwise, the device could be overloaded or functional problems could occur.
- Do not expose the device to rain, moisture, vapors or liquids.

- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!

- Ensure adequate ventilation to prevent damage due to overheating.

  Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.

  Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.