

HDMI dongle for modular KVM consoles, RJ45 to HDMI

DS-51203
EAN 4016032468653



HDMI Dongle

The DIGITUS® HDMI dongle for modular KVM consoles enables the remote control of a target computer via a single network cable in categories 5, 5e, 6, 6A or higher with RJ45 plug. It connects the KVM switch with the USB and HDMI jack of the target computer at ranges of up to 60 m in Full HD resolution. Ideal application for inaccessible server or computer systems. Power supply is provided through the USB connection of the connected device. No need for expensive KVM cables, use a single network cables to remotely control the computer of your choice with an HDMI connection.

Establishes a remote connection via network cable to a target computer with HDMI connection

- KVM console connection: 1 x RJ45
- Connection target computer: 1 x USB A, 1 x HDMI
- Video resolution: 1920 x 1080p max.
- Additional resolutions: 480P, 600P, 720P, 768P, 800P, 900P, 960P, 1024P, 1080P
- Maximum range: 60 m max.

- Operating systems: Can be used independently of the operating system
- Compatible with DIGITUS KVM series: DS-72210-4, DS-72210-5, DS-72211-4, DS-72211-5
- Power supply is provided via the target computer (USB)
- Operating temperature: 0°C to 50°C
- Operating humidity: 0% - 80% RH (non-condensing)
- Dimensions: 85 x 48 x 19 mm (LxWxH)
- Housing: Metal
- Weight: 120 g

Attributes

- Cascading possible: no
- Connectors KVM side: RJ45 jack, CAT 5 Installation
- Interface: CAT 5
- Number of ports: 1

Package contents

- 1 x HDMI dongle for modular KVM consoles, RJ45 to HDMI
- 1 x Quick installation guide

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm ³
Packaging Unit Carton	20	8.80	53.50	21.00	49.50	55,613.20
Packaging Unit Inside	5	2.20	29.00	40.00	44.00	51.04
Packaging Unit Single	1	0.44	4.80	8.50	2.00	81.60
Net single without Packaging	0	0.12	4.70	8.50	2.00	79.90

More images:



Safety notes

- This product is intended for indoor use only.
- Read all instructions.
- Follow all warnings and instructions on the device.
- Do not place this appliance on an unstable surface (such as a trolley, stand, table, etc.).
- If this appliance falls, it can cause serious damage.
- Do not use this appliance near water.
- Do not place this appliance near or above a radiator.
- The housing is equipped with openings for heat dissipation and ventilation. To prevent overheating during operation, the ventilation openings must not be blocked or covered.
- Do not place the appliance on a soft surface (e.g. bed, sofa, blanket, etc.). This will block the ventilation.
- The appliance must not be installed in a closed environment if adequate ventilation is not guaranteed.
- Do not spray any liquids onto the appliance.
- Disconnect the mains plug before cleaning. Do not use any liquid or foam cleaners.
- Clean the appliance with a damp cloth.
- Connect the device according to the power supply on the rating plate.
- This device is designed for the IT distribution system with 100 V - 230 V voltage.
- To prevent damage to the appliance, it is important that all appliances are properly earthed.
- Do not place any objects on the power cable and lay it in such a way as to avoid tripping hazards.
- If an extension cable is used for the appliance, make sure that the total capacity of all products using the cable does not exceed the current load.
- Ensure that the total current of all products connected to the socket does not exceed 15 A.
- Use a surge protector, a regulator or an uninterruptible power supply (UPS) to protect your system from sudden, temporary and reduced power.
- Secure the system cable and mains cable properly and ensure that no objects are pressing on the cable.
- Do not insert any objects into the appliance through the openings in the housing. There is a risk of a short circuit, which can lead to fire or electric shock.
- Do not attempt to repair the appliance yourself. Always contact an authorized customer service centre.
- If any of the following conditions occur, unplug the appliance and send it to an authorized service centre for repair
 - The mains cable or plug is damaged or worn;
 - Liquid has penetrated the appliance;
 - The device has been exposed to rain or water;
 - The device has been dropped or the housing has been damaged;
 - The function of the device has obviously changed;
 - The appliance cannot be operated as described in the operating instructions.