

Aluminum Smartphone / Tablet Stand

DA-90419
EAN 4016032475071



Aluminum Smartphone/Tablet Stand up to 10", silver

The stylish smartphone and tablet stand from DIGITUS® combines a modern look with a stable aluminum frame structure. The stand is suitable for smartphones or tablets with a display diagonal of up to 10". No slipping – the anti-slip pads beneath the stand ensure a secure hold even on smooth surfaces. The connection cable can also be guided through the rear frame opening in an orderly fashion to keep annoying cables out of the way.

Smartphone and Tablet Stand in elegant aluminum design for devices up to 10" display size

- Compatible with many smartphones and tablets with a display diagonal of up to 10"
- Suitable for housing thicknesses of up to 1.4 cm
- Cable management: Feedthrough on the back
- Anti-slip pads for secure hold
- Material: Aluminum alloy, silicone (pads)
- Dimensions: W 6.3 x D 8 x H 7.6 cm
- Weight: 100 g
- Color: Silver

Package contents

- 1 x Aluminum Smartphone / Tablet Stand

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm ³
Packaging Unit Carton	120	13.50	33.00	38.00	46.00	57.68
Packaging Unit Inside	1	0.11	0.00	0.00	0.00	0.00
Packaging Unit Single	1	0.11	6.80	8.50	8.20	473.96
Net single without Packaging	0	0.10	8.00	6.30	7.60	383.04

More images:





Safety notes

- Use charging adapters or power supply units in accordance with the instructions in the operating instructions to ensure optimum performance.
- Connect the charging adapter to an easily accessible socket in the voltage range between 100-240 V AC.
- Disconnect the charging adapter from the socket after use.
- Do not use the charging adapter with electronic devices that are outside the specifications of the charging adapter.
- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.