

# Wireless Optical Mouse, 3 buttons, Silent

DA-20161  
EAN 4016032482864



## Wireless Optical Mouse 3D, 2.4 GHz 1000 dpi, black

The reliable optical Office Mouse is specially designed for use on PC as well as notebook. The optical mouse offers maximum flexibility, thanks to the 2 buttons and scroll wheel. The ergonomic design offers a high level of comfort and makes the mouse equally suitable for right- and left-handed users. The fast scroll wheel is ideally suited for quick navigation. The high-resolution 1200 dpi optical sensor works on almost any surface.

### Comfortable and reliable control for your workplace

- Function buttons: Left/right click, scroll wheel
- Wireless frequency: 2.4 GHz
- Wireless range: 10 m max.
- Operating voltage: 1.5 V DC / 25 mA
- High-resolution optical sensor with 1200 dpi
- Plug & Play – no additional drivers required
- Power supply: 1 x AA battery (not included)

- On/off switch underneath the mouse
- Nano Wireless USB Receiver can be stored in mouse
- Operating systems: Windows 8 and above, macOS 10.10 and above, Android 4.3 and above
- Operating temperature: -20 °C to +60 °C
- Operating humidity: <85% RH (non-condensing)
- Dimensions of mouse: (W x D x H) 63 x 105.73 x 38.26 mm
- Dimensions of Nano Receiver: (W x D x H) 13.20 x 18.59 x 5.58 mm
- Material: ABS
- Color: Black
- Weight of mouse: 62.2 g
- Weight of Nano Receiver: 1.6 g

### Package contents

- 1 x USB mouse:
- 1 x USB Nano Receiver
- 1 x QIG

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	40	4.50	34.00	28.00	28.00	26,656.00
Packaging Unit Inside	1	0.11	16.00	18.00	4.00	1,152.00
Packaging Unit Single	1	0.11	12.00	8.00	5.00	480.00
Net single without Packaging	0	62.00	6.30	10.60	3.70	247,086.00

## More images:





#### Safety notes

- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.