# Wireless Optical Mouse, 6 buttons, 1600 dpi

DA-20162 EAN 4016032482871





#### Wireless Optical Mouse 6D, 2.4 GHz 800/1000/1600 dpi, black-grey

The optical Business Mouse was specially designed for use on PCs as well as notebooks. The device offers maximum flexibility, thanks to the 6 buttons and scroll wheel. With the help of 2.4 GHz technology, you can freely set up the mouse in your working environment, whether in the office or at home. The Business Mouse allows accurate control of the notebook or PC through its functions and features. The high-resolution optical sensor with up to 1600 DPI works with high precision on almost any surface.

## Comfortable and reliable control for your workplace

- Function buttons: Left/right click, scroll wheel, DPI button,
- forward/back buttons.
- Wireless frequency: 2.4 GHz
- Wireless range: 10 m max.
- Operating voltage: 5 V DC / 25 mA max.
- 3 DPI settings: 1600 / 1200 / 800
- Plug & Play no additional drivers required

- Power supply: 1 x AA battery (not included)
- On/off switch underneath the mouse
- Nano Wireless USB Receiver can be stored in mouse
- Operating systems: Windows 8 and above, macOS 10.10 and above, Android 4.3 and above
- Operating temperature: -20 °C to +60 °C
- Operating humidity: <85% RH (non-condensing)
- Dimensions of mouse: (W x D x H) 59.25 x 100.84 x 36.00 mm
- Dimensions of Nano Receiver: (W x D x H) 13.20 x 18.59 x 5.58
  mm
- Material: ABS
- Color: Black/gray
- Weight of mouse: 60 g
- Weight of Nano Receiver: 1.6 g


#### **Package contents**

- 1 x USB mouse:
- 1 x USB Nano Receiver
- 1 x OIG

	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm³
Packaging Unit Carton	40	4.80	34.00	28.00	28.00	26,656.00
Packaging Unit Inside	1	0.12	18.00	11.00	4.00	792.00
Packaging Unit Single	1	0.12	12.00	8.00	5.00	480.00
Net single without Packaging	0	64.00	6.60	10.30	3.70	251,526.00

# Logistics

## More images:



# Safety notes

- Do not expose the device to rain, moisture, vapors or liquids. •
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock! •
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device. Disconnect the appliance from the power supply and the connected devices before cleaning. Clean the device with a dust-free cloth. •
- •
- •