

ednet USB 2.0 Multi Card Reader

85241
EAN 4054007852410



USB 2.0 Card reader, 4-port Supports MS,SD,T-flash,CF formats, Black

ednet's USB 2.0 Multi Card Reader reads and writes data to your notebook or PC at high speed. Thanks to Plug & Play, you simply connect the card reader to your computer and it is ready to start the data transfer. Can read and write to up to ten different card formats. ednet's USB 2.0 Multi Card Reader offers downward compatibility with USB 1.1, meaning that you can also work with older notebooks and PCs without any problems. Thanks to its small, compact housing, it can be placed anywhere, such as at home, the office or in your notebook case, allowing for use wherever you may be!

Reads and writes data at high speed.

- Four USB 2.0 card slots
- Features four card slots for Compact Flash, SD Card, Micro SD/SDHC Card, Memory Sticks
- Supports data transfer rates in high-speed (480 Mbps) and full-speed (12 Mbps)
- Integrated USB connecting cable, 7 cm
- Compatible with Windows, Mac, Linux
- Dimensions: 1.3 x 2.4 x 9 cm
- Color: black

Package contents

- USB 2.0 Multi Card Reader, 4-Port
- Manual

Logistics						
	Number (pcs)	Weight (kg)	Depth (cm)	Width (cm)	Height (cm)	cm ³
Packaging Unit Carton	50	4.20	42.00	31.60	25.00	33,180.00
Packaging Unit Inside	1	0.08	17.60	10.00	2.70	475.20
Packaging Unit Single	1	0.08	17.60	10.00	2.70	475.20
Net single without Packaging	1	0.03	9.00	2.40	1.30	0.00

More images:





Safety notes

- Overloading can lead to overheating and damage to the appliance or the connected peripherals.
- If necessary, use an external power supply to ensure stable performance.
- If devices such as external hard disks or printers that require a high power consumption are connected, the device should be used with an external power supply. Otherwise, the device could be overloaded or functional problems could occur.
- Do not expose the device to rain, moisture, vapors or liquids.
- Do not insert any objects into the device.
- Do not attempt to repair the unit or open the housing without authorization. You risk an electric shock!
- Ensure adequate ventilation to prevent damage due to overheating.
- Dust, moisture, vapors and strong cleaning agents or solvents can cause damage to the device.
- Disconnect the appliance from the power supply and the connected devices before cleaning.
- Clean the device with a dust-free cloth.

EU responsible person

EU based economic operator ensuring the product complies with the required regulations.

ASSMANN Electronic GmbH
Auf dem Schüffel 3
Lüdenscheid, Germany
<https://www.assmann.com>
info@assmann.com